

## CODE UNIQUE's Instruction

### Things you need

- \* PS3 with kmeaw's 3.55 CFW installed
- \* CHT Dongle FOR 3.55



### How to use CODE UNIQUE


Step 1: plug the cheat dongle in the usb port of your ps3 and turn on your ps3. beneath Game Meum, you will find the floder that named "CU", choose it and press "O" to execute it. **Note: If there is a micro sd card in the slot of your dongle, it must be removed and restart your ps3 before the cheat dongle can work normally.**

### CODE UNIQUE's ICON




Step 2: all ps3 games that stored in the external and internal hard drive will be displayed as a game list.

In the meantime, code unique will detect all the games automatically and confirm which games match with the built-in code library. If matching successfully, you will find that a **key icon** display at the end of the game name. If no matching, you will no longer see it.



Step 3: Press "O" to enter, A list of the cheat options appears. You can choose one or more options, it's up to you, then press "start" to run the game. (before starting, a few of games maybe need a **leading disc** into the drive of the PS3). That's all, an amazing and awesome software



## FAQ

- **Q: Is the latest CHT dongle easy to install?**

- A: without installation and the need of opening up your PS3.

- **Q: How to use it?**

- A: Just plug it into your PS3 USB port, Press the POWER Key, without a special way of booting up.

- **Q: It support upgrades?**

- A: 100% Upgradeable, Compatible with all PS3 models – Fat and Slim.

- **Q: What is the warranty?**

- A: PS3break is sold with 1 year warranty. All our resellers will take care of warranty issues.

- **Q: How to get started in GAME section?**

- A: Without a leading disc, just Using self-developed, built-in, all-in-one Apps - CODE UNIQUE

- **Q: which version of ps3 firmware will this work?**

- A: The latest CHT dongle works with 3.55 CFW.

- **Q: If PS3 system is under 3.55, What should I do?**

- A: Very easy. step 1: Update your PS3 to the original PS3 firmware 3.55(regardless of what CFW your currently are). step 2: Download the required files for Kmeaw 3.55 or Rebug 3.55 and rewrite the original PS3 firmware 3.55.

- **Q: Does it support this way which play genuine games with it?**

- A: supporting completely.

- **Q: Are there any special provisions using it with PS3 Fat and Slim?**

- A: Without any provisions, exactly the same.

- **Q: How to recognize that my dongle is for 3.41 OFW or 3.55 CFW?**

- A: Without a TF card in the dongle, if the U disk popup, it means that your dongle is for 3.41 OFW, if the computer prompts you that found a new device, then your dongle is for 3.55 CFW.

- **Q: How to judge whether the dongle is working normally?**

- A: Beneath Game Meum, find a icon named "CU" and enter it. press "□" button on the control handle, a game cheat list will be displayed, it means that your dongle is working normally, otherwise you didn't see anything.

- **Q: After i plug the dongle in the computer, it prompts me that found a new device, what should I do?**

- A: you must insert a TF card to the dongle, and then the computer can identify U disk of the dongle. If insert into a PS3, the TF must be pulled out, otherwise the PS3 can not recognize it.

- **Q: After startup, the PS3 prompts me that found "an unknown device", why?**

- A: This is normal.